CABINET PARTS

For Models: GEX9868JQ1, GEX9868JT1
(Designer White) (Biscuit)

29" Electric Dryer



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: GEX9868JQ1, GEX9868JT1
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT3397618	Instructions, Installation
	LIT8314840	Use & Care Guide
	LIT8530234	Tech Sheet
	LIT3977777	Wiring Diagram
		Following May Be Purchased
		DO−IT−YOURSELF REPAIR MANUALS
	LIT677818	Dryer
2	343641	Screw, 10−16 x 1/2
3	693995	Screw, 8−18 x 3/8
5	3396795	Cover, Block
6	342043	Screw, 10−32 x 3/8
7	3396805	Panel, Rear
8	98669	Locator, Top
9	18849	Pad, Top Hinge
10	3406107	Door Switch Assembly
11	697773	Screw, 6−20 x 7/8
12	3402709	Board, Sound Dampening
13	3357011	Screw, 10−16 x 1/2
14	692495	Spring, Door (2)
15	3394083	Clip, Front Panel (2)
16	3392100	Foot, Dryer
	279810	Foot−Optional (Extended Length Package of 2) (Not Included)
17	279318	Terminal, Tinned & Brass (3) (Includes Illus. 34)
18		Cabinet
	8530603	White
	8530606	Biscuit
19	98234	Clip, Ground
20	18776	Lock, Front Top (2)
21		Panel, Front
	695620	White
	3977244	Biscuit
23	685203	Clip, Felt Pad (3)
24	3389441	Catch, Door Assembly
26	337189	Clip, Hinge (2)
27	694091	Screw, 8−18 x 3/8
28	8066056	Hinge, R.H.
	8066057	Hinge, L.H.
29	696144	Strike, Door
30	695737	Door, Rear
31		Door, Front
	3393549	White
	3977241	Biscuit
32		Handle, Door
	690270	White
	3977242	Biscuit
33	3406129	Seal & Bearing Assembly
34	279393	Terminal Block Kit (For Terminal Block)
35	697776	Screw, 10−32 x 5/8
36	3397659	Block, Terminal
37	238088	Hinge, Top (2)
38	3394332	Idler & Slide Assembly
39	8066065	Belt, Drive
40	348780	Base, Motor
41	3400500	Bolt, 5/16−18 x 3/4
42	3394341	Pulley, 60 Hz.
43	661654	Motor Assembly 60 Hz.
44	660658	Clamp, Motor
45	3404162	Clamp, Motor (W/Shield)
46	3390731	Seal, Door
47	3393008	Screw, 10−16 x 1/2

TOP AND CONSOLE PARTS

For Models: GEX9868JQ1, GEX9868JT1
(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Models: GEX9868JQ1, GEX9868JT1
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	8274261	Panel, Rear Console
2	3978802	Control Board
3	693995	Screw, Hex Head
4		Cap, End (L.H.)
	8271365	White
	8271368	Biscuit
5	237446	Washer
6	388326	Screw, Console
7	3355753	Clip, Ground
8		Cap, End (R.H.)
	8271359	White
	8271362	Biscuit
9	3393918	Screw, 8−18 x 5/16
10	349639	Screen, Lint
11		Cover, Lint Screen
	8283378	White
	8283380	Biscuit
12	3978605	Hinge, R.H.
	3978606	Hinge, L.H.
13	688983	Screw, 8−18 x 5/8
14	3400826	Screw, 8−18 x 3/4
15	3395683	Connector (Motor)
16		Top
	8271395	White
	8271397	Biscuit
18	3394427	Clip−Harness
19	297535	Bumper, Lint Lid
20	3390646	Screw, Mounting (8−18 x 5/16)
21	357213	Nut, Push−In (2)
22	8299902	Harness, Wiring
23	94614	Terminal
24	3936144	Connector
25	8274305	Bracket, Control
26		Panel, Control
	8274398	White
	8274399	Biscuit
27	343641	Screw, 10−16 x 1/2

OPTIONAL PARTS (NOT INCLUDED)

Illus. No.	Part No.	DESCRIPTION
		ACCESSORY PARTS
	279948	Kit, Dryer Repair
		PAINT, TOUCH−UP (1/2oz.)
	72017	White
	4392899	Biscuit
		PAINT, PRESSURIZED SPRAY (12 oz.)
	350930	White
	350938	Primer, Gray
	4392901	Biscuit
		PAINT, BULK (1 qt.)
	799344	White (Uncut)
	4392900	Biscuit(Uncut)

BULKHEAD PARTS

For Models: GEX9868JQ1, GEX9868JT1
(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: GEX9868JQ1, GEX9868JT1
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2	487909	Screw, 8−18 x 1/2
3	3388703	Washer−Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8−18 x 3/8
6	696302	Shield, Exhaust
7	3390719	Thermal Fuse
8	3976615	Thermistor
9	3977393	Thermal, Cut−Off (Hi−Limit Thermostat Illus. No.15 Included)
10	694089	Wheel, Blower (Includes Illus. No. 22)
11	3404301	Housing, Blower
12	3398161	Clip
13	343641	Screw, 10−16 x 1/2
14	3397566	Box, Heater
15	3977767	Thermostat, 221°F (105°C)
16	3977373	Bracket, Drum Light
17	3403585	Element, Heater
18	8066086	Drum Hole Plug
19	279457	Wire Kit, Terminal (For Heater Element Wiring Harness Repair)
20	489463	Screw, 8−18 x 5/8
21	3406653	Harness, Sensor
22	3394196	Seal, Blower
23	3406839	Dry Rack Assembly
24	692989	Dry Rack Bracket
25	3406656	Pad, Sensor
26	3406124	Bulb
27	3402841	Lens, Drum Light
28	690997	Ring, Tri
29	3399506	Shaft, L.H.
30	3399507	Shaft, R.H.
31	3397588	Roller, Support
32	348197	Washer, Support
33	3359452	Nut, 3/8−16
34	3403414	Bulkhead
35	3403634	Socket Assembly
36	692526	Ring, Bearing (2)
37	97787	Screw, 11−16 x 3/4
38	3406130	Seal, Rear Drum
39	695587	Drum Assembly
40	692490	Baffle, Drum (2)
41	3976434	Bracket, Support
42	90296	Clip
43	3403636	Baffle, Drum (1)
44	339956	Seal
45	3390646	Screw, 8−18 x 5/16